

Ph: (916) 638-2722 / Fax: (916) 638-2725


## **Installation Information**

## Item #P1018

## **Gooseneck Leg Tub Faucet with Variable Centers**

Warranted only when installed by a qualified, licensed plumber. Please use Teflon tape on all threaded connections.

- 1. Shut off the water supply to the fixture before installation.
- 2. Thread the shorter end of the hook-up inlet tubes into the backside of the swing arm coupler. Loosely tighten the swing arm couplers to allow for the centers adjustment.
- 3. Insert the inlet nipples through the 2 holes on the tub. Screw the lock nuts onto the threaded nipples and tighten to secure the faucet to your tub.
- 4. Tighten the nut on the coupler to secure to the faucet body at the desired placement.
- 5. Attach your supply lines to the 1/2" IPS faucet inlet tubes.
- 6. Make no adjustments to valves or valve stems. They are tested at the factory for optimum performance.



## Parts Included:

- Faucet Body w/Arch Spout
- Swing Arms (pair)
- Handles (2)
- ½" IPS Inlet Nipples (2)
- Lock Down Nuts (2)
- Supply Nut/ Washer (2)

Leg tub filler outlet shall be installed minimum 2" above the flood level rim of the fixture